


# Flowflex™

## SARS-CoV-2

### Antigen Rapid Test (Self-Testing)



A rapid test for the detection of SARS-CoV-2 nucleocapsid antigens in anterior nasal swab specimens.  
For in vitro diagnostic use only. For self-testing.



The Global Leader of Rapid Test with **26** Years Experience.



Fast



Accurate



Easy to Use



Reliable



CE Marked

**ACON®**

# Flowflex SARS-CoV-2 Antigen Rapid Test (Self-Testing)

The SARS-CoV-2 Antigen Rapid Test is a lateral flow test for the qualitative detection of the nucleocapsid antigen from SARS-CoV-2 in anterior nasal swab specimens directly from individuals suspected of COVID-19 within the first seven days of the onset of symptoms. The test can also test specimens from individuals without symptoms.

- **Specimen:** Anterior nasal swab specimens
- **Test Time:** Results at 15 min.
- **Shelf life:** 24 months
- **Storage temperature:** 2-30°C
- **Accuracy:** 98.8%
- **Sensitivity:** 97.1%
- **Specificity:** 99.5%



1T



5T



25T

## Test Procedure


### 1. Test Preparation

#### A. Open your test kit:




#### B. You should have:

Note: For 1T and 5T, the hole is on the kit box.



Tube Holder  
(for 25T only)



Disposable Swab



Test cassette



Extraction Buffer Tube



Package Insert




Waste Bag

#### C. Wash or sanitize your hands.



#### D. Read the instructions.




#### E. Check the expiration date.



#### F. Open the pouch.



#### G. Check the cassette



### 2. Specimen Collection


#### COLLECTION BY AN ADULT CAREGIVER




#### SELF COLLECTION




or




1  
Insert the entire absorbent tip of the swab into one nostril. Using gentle rotation, push the swab less than 2.5 cm from the edge of the nostril.



2  
Rotate the swab 5 times brushing against the inside of the nostril.




3  
Remove the swab and insert it into the other nostril.




4  
Remove swab from the nostril.


### 3. Sample Preparation




1  
Unscrew the dropper cap.




2  
Insert the swab into the tube and swirl for 30 seconds.



3  
Rotate the swab 5 times while squeezing the side of the tube.




4  
Remove the swab while squeezing the tube.



5  
Screw the dropper cap.

## 4. Running the Test



## Ordering Information

| Product Name  | Catalog No.  | Format   | Specimen             | Package      |
|---|--------------|----------|----------------------|--------------|
| Flowflex SARS-CoV-2 Antigen Rapid Test (Self-Testing) | L031-11855 ✓ | Cassette | Anterior nasal swabs | 1 Test/Kit   |
|   | L031-118A5 ✓ | Cassette | Anterior nasal swabs | 5 Tests/Kit  |
|   | L031-118Q5 ✓ | Cassette | Anterior nasal swabs | 25 Tests/Kit |

✓ CE Marked



**ACON Biotech (Hangzhou) Co., Ltd.**  
 No.210 Zhenzhong Road, West Lake District, Hangzhou, P.R.China, 310030  
 Tel: +86-571-8118 9706 / Fax: +86-571-8777 5781 / Email: [information@aconlab.com.cn](mailto:information@aconlab.com.cn)  
[www.aconbio.com](http://www.aconbio.com)